

COMPUTING

SSF for MaxCore™ MC3000 Platform

Command Line Interface Guide

P/N: 6806800T87G

January 2018

ARTESYN[™]
EMBEDDED TECHNOLOGIES

© Copyright 2017-2018 Artesyn Embedded Technologies, Inc.
All rights reserved.

Trademarks

Artesyn Embedded Technologies, Artesyn and the Artesyn Embedded Technologies logo are trademarks and service marks of Artesyn Embedded Technologies, Inc. All other names and logos referred to are trade names, trademarks, or registered trademarks of their respective owners. © 2017-2018 Artesyn Embedded Technologies, Inc. All rights reserved. For full legal terms and conditions, please visit www.artesyn.com/legal.

Notice

While reasonable efforts have been made to assure the accuracy of this document, Artesyn assumes no liability resulting from any omissions in this document, or from the use of the information obtained therein. Artesyn reserves the right to revise this document and to make changes from time to time in the content hereof without obligation of Artesyn to notify any person of such revision or changes.

Electronic versions of this material may be read online, downloaded for personal use, or referenced in another document as a URL to an Artesyn website. The text itself may not be published commercially in print or electronic form, edited, translated, or otherwise altered without the permission of Artesyn.

It is possible that this publication may contain reference to or information about Artesyn products (machines and programs), programming, or services that are not available in your country. Such references or information must not be construed to mean that Artesyn intends to announce such Artesyn products, programming, or services in your country.

Limited and Restricted Rights Legend

If the documentation contained herein is supplied, directly or indirectly, to the U.S. Government, the following notice shall apply unless otherwise agreed to in writing by Artesyn.

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data clause at DFARS 252.227-7013 (Nov. 1995) and of the Rights in Noncommercial Computer Software and Documentation clause at DFARS 252.227-7014 (Jun. 1995).

Contact Address

Artesyn Embedded Technologies
Marketing Communications
2900 S. Diablo Way, Suite 190
Tempe, Arizona 85282

Contents

About this Manual	11
1 Introduction	15
1.1 Accessing SSF using CLI	15
1.2 Connecting to CLI	16
2 Access Control Commands	19
2.1 show	20
2.2 user	20
2.3 group	21
2.4 show-all	21
2.5 user, group, and membership	22
3 Configuration Commands	23
3.1 snapshot	23
3.2 reload	23
3.3 commit	24
3.4 system-upgrade-initiate	24
3.4.1 system-upgrade-status	25
4 Hardware Platform Manager Commands	31
4.1 applyPEXConfiguration	34
4.2 assignIODeviceFunctionToCPU	35
4.3 createIODeviceFunctions	35
4.4 destroyAllIODeviceFunctions	36
4.5 eventLog	36
4.6 getCPUAssignedFunctions	37
4.7 getCPUVirtualNICFunctionCount	37
4.8 getChassisPayloadPowerPolicy	38
4.9 getCoolingPolicy	38
4.10 getFunctionAssignedCPUAddress	39
4.11 getPEXMode	39
4.12 getSATAAssignment	40

4.13	getShelfHostAddress	40
4.14	getUSBAssignment	41
4.15	getZoneType	41
4.16	listAlarms	41
4.17	listAvailableCPUs	42
4.18	listAvailableIODevices	42
4.19	listShelfInfo	43
4.20	removeIODeviceFunctionFromCPU	43
4.21	resetPEXConfiguration	44
4.22	setCPUVirtualNICFunctionCount	44
4.23	setChassisPayloadPowerPolicy	45
4.24	setCoolingPolicy	45
4.25	setPEXMode	45
4.26	setSATAAssignment	46
4.27	setUSBAssignment	46
4.28	getBIOSBootOrder	47
4.29	getBIOSConsoleRedirectionParameters	47
4.30	getBIOSBootConfiguration	48
4.31	getBIOSPeripheralConfiguration	48
4.32	getBIOSIIOConfiguration	49
4.33	getBIOSSATAConfiguration	49
4.34	getBIOSVideoConfiguration	50
4.35	getBIOSUSBConfiguration	50
4.36	getBIOSProcessorConfiguration	51
4.37	getBIOSPowerManagementConfiguration	51
4.38	getBIOSThermalConfiguration	52
4.39	getBIOSMemoryConfiguration	52
4.40	getBIOSCommonRefcodeConfiguration	53
4.41	setBIOSBootOrderNew	53
4.42	setBIOSBootOrderDefault	54
4.43	setBIOSBootOrderbyIndex	55
4.44	setBIOSConsoleRedirectionParameters	56
4.45	setBIOSBootConfiguration	57
4.46	setBIOSPeripheralConfiguration	58
4.47	setBIOSIIOConfiguration	58
4.48	setBIOSSATAConfiguration	59

4.49	setBIOSVideoConfiguration	60
4.50	setBIOSUSBConfiguration	61
4.51	setBIOSProcessorConfiguration	61
4.52	setBIOSPowerManagementConfiguration	62
4.53	setBIOSThermalConfiguration	63
4.54	setBIOSMemoryConfiguration	64
4.55	setBIOSCommonRefcodeConfiguration	65
4.56	powerOffAllApplicationCPUs	65
4.57	setShelfAddress	66
4.58	getShelfAddress	67
4.59	setBMCIPAddress	67
4.60	getBMCIPAddress	68
4.61	listShelves	68
4.62	addShelf	69
4.63	removeShelf	69
4.64	modifyShelf	70
4.65	setSsfHostInterfaceName	71
4.66	getSsfHostInterfaceName	71
4.67	setDefaultConfiguration	71
4.68	getDiscoveryStatus	72
4.69	setPXEBootEnvironmentForCPU	72
4.70	getPXEBootConfigurationForCPU	73
5	System Commands	75
5.1	CLI Commands in disable mode	75
5.2	CLI commands in enable mode	76
5.3	CLI commands in config mode	78
5.4	CLI Commands in System Mode	82
5.5	exit	84
5.6	CLI Commands for Shelf Mode	84
5.7	CLI Commands for PCIeSlot Mode	86
5.8	CLI Commands for PCIeCard Mode	87
5.9	CLI Commands for CPU Mode	88
5.10	CLI Commands for BIOS Configuration mode	90
5.11	CLI Commands for VEE mode	96

5.12	CLI Commands for Linux Application mode	98
6	System Log Collection Commands.....	101
6.1	collectlog	101
6.2	listlog	101
6.3	deletelog	102
6.4	ssflogsize	102
6.5	downloadlog	102
A	Related Documentation.....	103
A.1	Artesyn Embedded Technologies - Embedded Computing Documentation	103

List of Tables

Table 1-1	Command Line Editing Features	16
Table 2-1	Parameters of the show command	20
Table 2-2	Parameters of the user command	21
Table 2-3	Parameters of the group command	21
Table 2-4	Parameters of the user, group, and membership commands	22
Table 3-1	Parameters of snapshot command	23
Table 3-2	Parameters of reload command	23
Table 3-3	Parameters of commit command	24
Table 3-4	Parameters of systemupgrade command	24
Table 4-1	Parameters of applyPEXConfiguration	35
Table 4-2	Parameters of assignIODeviceFunctionToCPU	35
Table 4-3	Parameters of createIODeviceFunctions	36
Table 4-4	Parameters of destroyAllIODeviceFunctions	36
Table 4-5	Parameters of eventLog	37
Table 4-6	Parameters of getCPUAssignedFunctions	37
Table 4-7	Parameters of getCPUVirtualNICFunctionCount	38
Table 4-8	Parameters of getChassisPayloadPowerPolicy	38
Table 4-9	Parameters of getCoolingPolicy	39
Table 4-10	Parameters of getFunctionAssignedCPUAddress	39
Table 4-11	Parameters of getPEXMode	40
Table 4-12	Parameters of getSATAAssignment	40
Table 4-13	Parameters of getShelfHostAddress	40
Table 4-14	Parameters of getUSBAssignment	41
Table 4-15	Parameters of getZoneType	41
Table 4-16	Parameters of listAlarms	42
Table 4-17	Parameters of listAvailableCPUs	42
Table 4-18	Parameters of listAvailableIODevicees	42
Table 4-19	Parameters of listShelfInfo	43
Table 4-20	Parameters of removeIODeviceFunctionFromCPU	43
Table 4-21	Parameters of resetPEXConfiguration	44
Table 4-22	Parameters of setCPUVirtualNICFunctionCount	44
Table 4-23	Parameters of removeIODeviceFunctionFromCPU	45
Table 4-24	Parameters of setCoolingPolicy	45
Table 4-25	Parameters of setPEXMode	46
Table 4-26	Parameters of setSATAAssignment	46
Table 4-27	Parameters of setUSBAssignment	47

Table 4-28	Parameters of getBIOSBootOrder	47
Table 4-29	Parameters of getBIOSConsoleRedirectionParameters	48
Table 4-30	Parameters of getBIOSBootConfiguration	48
Table 4-31	Parameters of getBIOSPeripheralConfiguration	49
Table 4-32	Parameters of getBIOSIIOConfiguration	49
Table 4-33	Parameters of getBIOS SATAConfiguration	50
Table 4-34	Parameters of getBIOSVideoConfiguration	50
Table 4-35	Parameters of getBIOSUSBConfiguration	51
Table 4-36	Parameters of getBIOSProcessorConfiguration	51
Table 4-37	Parameters of getBIOSPowerManagementConfiguration	52
Table 4-38	Parameters of getBIOSThermalConfiguration	52
Table 4-39	Parameters of getBIOSMemoryConfiguration	53
Table 4-40	Parameters of getBIOSCommonRefcodeConfiguration	53
Table 4-41	Parameters of setBIOSBootOrderNew	54
Table 4-42	Parameters of setBIOSBootOrderDefault	55
Table 4-43	Parameters of setBIOSBootOrderbyIndex	55
Table 4-44	Parameters of setBIOSConsoleRedirectionParameters	56
Table 4-45	Parameters of setBIOSBootConfiguration	57
Table 4-46	Parameters of setBIOSPeripheralConfiguration	58
Table 4-47	Parameters of setBIOSIIOConfiguration	59
Table 4-48	Parameters of setBIOS SATAConfiguration	59
Table 4-49	Parameters of getBIOSVideoConfiguration	60
Table 4-50	Parameters of setBIOSUSBConfiguration	61
Table 4-51	Parameters of setBIOSProcessorConfiguration	62
Table 4-52	Parameters of setBIOSPowerManagementConfiguration	63
Table 4-53	Parameters of setBIOSThermalConfiguration	64
Table 4-54	Parameters of setBIOSMemoryConfiguration	64
Table 4-55	Parameters of setBIOSCommonRefcodeConfiguration	65
Table 4-56	Parameters of powerOffAllApplicationCPUs	66
Table 4-57	Parameters of setShelfAddress	67
Table 4-58	Parameters of getShelfAddress	67
Table 4-59	Parameters of setBMCIPAddress	68
Table 4-60	Parameters of getBMCIPAddress	68
Table 4-61	Parameters of addShelf	69
Table 4-62	Parameters of removeShelf	70
Table 4-63	Parameters of modifyShelf	70

Table 4-64	Parameters of setSsfHostInterfaceName	71
Table 4-65	Parameters of setDefaultConfiguration	71
Table 4-66	Parameters of getDiscoveryStatus	72
Table 4-67	Parameters of getDiscoveryStatus	72
Table 4-68	Parameters of getDiscoveryStatus	73
Table 5-1	Parameters of Disable mode commands	76
Table 5-2	Parameters of Enable mode commands	77
Table 5-3	Parameters of Configure mode commands	82
Table 5-4	Parameters of System mode commands	83
Table 5-5	Parameters of Shelf mode commands	84
Table 5-6	Parameters of PCIeSlot mode commands	87
Table 5-7	Parameters of PCIeCard mode commands	88
Table 5-8	Parameters of CPU mode commands	89
Table 5-9	Parameters of BIOS mode commands	90
Table 5-10	Parameters of VEE mode commands	96
Table 5-11	Parameters of Linux Application mode commands	99
Table A-1	Artesyn Embedded Technologies - Embedded Computing Publications	103

About this Manual

Overview of Contents

This guide provides detailed information on usage of Command Line Interface (CLI) to work with System Services Framework (SSF). The following list gives an overview of the chapters described in this document.

- [Chapter 1, *Introduction*](#) provides overview of SSF, SSF key features, accessing of SSF using CLI, and connecting to CLI.
- [Chapter 2, *Access Control Commands*](#) provides Access Control commands and their definitions in detail.
- [Chapter 3, *Configuration Commands*](#) provides Snapshot, Reload, and Commit commands and their definitions in detail.
- [Chapter 4, *Hardware Platform Manager Commands*](#) provides Hardware Platform Manager commands and their definitions in detail.
- [Chapter 5, *System Commands*](#) provides System related commands and their definitions in detail.
- [Chapter 6, *System Log Collection Commands*](#) provides System Log Collection commands and their definitions in detail. Also, describes how to collect system logs from different cards to SSF Core.
- [Appendix A, *Related Documentation*](#) lists the relevant manuals.

Abbreviations

The following table lists the abbreviations used in this guide.

Abbreviation	Definition
BMC	Baseboard Management Controller
CSIM	Common System Information Model
HPM	Hardware Platform Manager
PEE	Physical Execution Environment
PCIe	Peripheral Component Interconnect Express
VEE	Virtual Execution Environment

Abbreviation	Definition
SRstackware	Switching and Routing stackware
SSF	System Services Framework
VEE	Virtual Execution Environment
VF	Virtual Function

Conventions

The following table describes the conventions used throughout this manual.

Notation	Description
0x00000000	Typical notation for hexadecimal numbers (digits are 0 through F) used for addresses, offsets, and so on
0b0000	Same for binary numbers (digits are 0 and 1)
bold	Used to emphasize a word
Screen	Used for on-screen output and code related elements or commands in body text
Courier + Bold	Used to characterize user input and to separate it from system output
<i>Reference</i>	Used for references and for table and figure descriptions
File > Exit	Notation for selecting a submenu
<text>	Notation for variables and keys
[text]	Notation for software buttons to click on the screen and parameter description
...	Repeated item for example node 1, node 2, ..., node 12
.	Omission of information from example/command that is not necessary at the time being
..	Ranges. For example: 0..4 means one of the integers 0,1,2,3, and 4 (used in registers)
	Logical OR

Summary of Changes

Part Number	Date	Description
6806800T87G	January 2018	Added a new command, power policy in Table 5-8 .
6806800T87F	July 2017	Added chapters setDefaultConfiguration on page 71, getDiscoveryStatus on page 72, setPXEBootEnvironmentForCPU on page 72, and getPXEBootConfigurationForCPU on page 73.
6806800T87E	April 2017	Updated Chapter 5, CLI commands in config mode , on page 78. Added chapters powerOffAllApplicationCPUs , setShelfAddress , getShelfAddress , setBMCIPAddress , getBMCIPAddress , listShelves , addShelf , removeShelf , modifyShelf , setSsfHostInterfaceName and getSsfHostInterfaceName .
6806800T87D	March 2017	Added CLI Commands for PCIeSlot Mode on page 86, CLI Commands for PCIeCard Mode on page 87, CLI Commands for CPU Mode on page 88, CLI Commands for BIOS Configuration mode on page 90, CLI Commands for VEE mode on page 96, CLI Commands for Linux Application mode on page 98, setBIOSBootOrderDefault on page 54, setBIOSBootOrderbyIndex on page 55, and system-upgrade-initiate on page 24.
6806800T87C	November 2016	Updated Chapter 1, Introduction , on page 15, Chapter 2, Access Control Commands , on page 19, Chapter 3, Configuration Commands , on page 23, Chapter 4, Hardware Platform Manager Commands , on page 31, and Chapter 5, System Commands , on page 75.
6806800T87B	September 2016	Added a new chapter SharpMedia PCIe-8120 Commands on page 57.
6806800T87A	January 2016	Initial version

System Services Framework (SSF) is a management and configuration interface to Artesyn's hardware and software products. It facilitates system level configuration and management access to SSF managed hardware and software components, through Web, CLI, and XML protocol interfaces.

SSF learns all the hardware and system software components to represent in Common System Information Model (CSIM). It provides a user interface to manage servers from a single management interface and stores the attributes and corresponding configurations of each hardware or software component in the PostgreSQL database for persistency.

SSF key features:

- Access, Authentication, and Authorization
- Configuration persistency, reload, and rollback
- Hierarchical representation of System Model
- Dynamic population of System Model
- Remote system configuration management, firmware upgrade, and system diagnosis

1.1 Accessing SSF using CLI

You can access SSF using the CLI. SSF provides a fully functional CLI with auto complete, history, and help features.

SSF CLI is a Telnet daemon that waits for inbound TCP connections. You can access the CLI through Telnet session. The CLI can serve multiple client sessions simultaneously, and the number of sessions supported by SSF is limited to "maxSessions" configured in `"/opt/ssf/etc/config/main/cli.cfg"`.

SSF CLI enables to traverse the system hierarchically and provides configuration and management access to the SSF system. All these hierarchies are represented as nodes.

Using CLI, you can:

- Edit SSF configuration
- View general system information
- Configure and manage all platform services, such as `syslog-ng` and `syslcu`
- Upgrade the firmware

The following table provides command line editing features of SSF CLI.

Table 1-1 Command Line Editing Features

Keywords	Description
Left and Right arrow keys	Allow you to move the cursor within the current command line.
Up and Down arrow keys	Allow you to browse through a command history.
BACKSPACE Key	Enables you to remove the character towards left.
TAB key	Completes the keyword being entered automatically.
"?" key	Provides you context help.
<cr>	Carriage return. System displays this command when you provide all mandatory arguments of a particular CLI command. It represents the command syntax completion.

1.2 Connecting to CLI

You can connect to the CLI after login into the SSF running Host, using External SSH Daemon with SSH Connection. This is the default behavior of SSF CLI.

- Start the **Telnet** connection from an already established secure shell.

```
[root@abts-ap-static-214 ~]# telnet localhost 11001
```

```
Trying ::1...
```

```
telnet: connect to address ::1: Connection refused
```

```
Trying 127.0.0.1...
```

```
Connected to localhost.
```

```
Escape character is '^']'.
```

```
Welcome to SSF CLI
```

```
Username: Admin
```

```
Password:
```

```
Access granted
```



```
>enable  
  
#configure terminal  
  
MaxCore(config)#
```

NOTICE

By default, the IP address is configured as **127.0.0.1** and the port numbers are 11001(CLI) and 15550 (XML).

Also the `cli.cfg` file configures:

- The maximum number of connections to the command line interface, default value is 5.
- The time out in seconds, default value is 300.

Access Control Commands

The access control commands allow you to access the authentication mode of the SSF. Using the access control commands, you can:

- Add new users
- Modify existing user details
- Delete existing users
- Create new groups and add users into it
- View the list of available users and groups.

To execute the access control commands, you should work in the privilege mode of CLI as shown below:

```
[root@abts-ap-static-214 ~]# telnet localhost 11001
```

```
Trying ::1...
```

```
telnet: connect to address ::1: Connection refused
```

```
Trying 127.0.0.1...
```

```
Connected to localhost.
```

```
Escape character is '^]'.  
>
```

```
Welcome to SSF CLI
```

```
Username: Admin
```

```
Password:
```

```
Access granted
```

```
>enable
```

```
#configure terminal
```

```
MaxCore(config)#
```

2.1 show

The `show` command in the authentication mode allows you to view the properties of users and groups. This command takes user name or group name as its parameters. When the parameter is `<user name>`, it displays the properties of the specified user name. When the parameter is `<group name>`, it displays the properties of the specified group name.

Syntax

```
#show {user | group} <username> | <groupname>
```

Table 2-1 Parameters of the show command

Argument	Description
<code><username></code>	Type the valid user name of whom you want to view the details. The name and password of the specified user are displayed.
<code><groupname></code>	Type the valid group name of which you want to view the details. The name and membership object of the specified group are displayed.

Example

```
#show user Admin
```

2.2 user

The user commands allow you to add, delete, and modify users from the user database.

To add a user

Syntax

```
#username <username> password <password>
```

To modify a user password

Syntax

```
#password <username> <password>
```

To delete a user

Syntax

```
#no username <username>
```

Table 2-2 Parameters of the user command

Argument	Description
<username>	Type the valid user name to be added, modified, or deleted
<password>	Type the corresponding password of the specified user name

2.3 group

The `group` command allows you to add new groups and delete existing groups.

To add a group**Syntax**

```
#group <groupname>
```

To delete a group**Syntax**

```
#no group <groupname>
```

Table 2-3 Parameters of the group command

Argument	Description
<groupname>	Type the valid group name to be added or deleted

2.4 show-all

The `show-all` command in authentication mode allows you to view the list of available users and groups. This command takes `user` or `group` as its parameters. When the parameter is `user`, it displays the list of all users added in SSF. When the parameter is `group`, it displays the list of all groups added in SSF.

Syntax

```
#show {user | group}
```

Example

```
#show user
```

2.5 user, group, and membership

The `user`, `group`, and `membership` commands allows you to add or delete users from the existing groups.

To add a user to a group

Syntax

```
#assign <username> to <groupname>
```

To delete a user from a group

Syntax

```
#remove <username> from <groupname>
```

Table 2-4 Parameters of the user, group, and membership commands

Argument	Description
<username>	Type the valid user name to be added or deleted from a group
<groupname>	Type the valid group name to which a user to be added or deleted

Configuration Commands

The following are the configuration commands available with SSF.

3.1 snapshot

The `snapshot` command stores the complete configuration of a component and all the objects under its hierarchy, to a specified file. With `disable` option, it will not copy read only configuration to snapshot and with `enable` option, it will copy read only configuration to snapshot.

Syntax

```
#snapshot output <configuration file to store> <disable|enable>
```

Table 3-1 Parameters of snapshot command

Argument	Description
<configuration file to store>	Type the file name into which the configuration of component is stored.
<disable enable>	disable will not copy read only configuration to snapshot. enable will copy read only configuration to snapshot.

3.2 reload

The `reload` command uploads the configuration of components collected at a particular hierarchy level, to the current configuration. This command is available at configuration level and any file that is stored using `snapshot` command can be reloaded. You can also modify the snapshot file before performing a reload operation.

Syntax

```
#reload script <configuration file to reload>
```

Table 3-2 Parameters of reload command

Argument	Description
<configuration file to reload>	Type the file name from which the configuration of component is to be reloaded to the current configuration.

Note: This command allows only to reload the snapshot taken/captured via CLI interface. In case of modifying the snapshot file before reload, make sure that inputs modified in the snapshot file are valid and syntactically correct. Any syntax errors or incorrect inputs may not result in any intimations or rollback.

3.3 commit

The `commit` command applies the changes made to the configuration file in the current configuration. This command supports rollback feature. In case of any failure while committing the configuration, system will be rolled back to the previous state.

Syntax

```
#commit configuration <Configuration Name>
```

Table 3-3 Parameters of commit command

Argument	Description
<Configuration Name>	Type the configuration name that you want to commit.

3.4 system-upgrade-initiate

The `system-upgrade-initiate` CLI command allows user to upgrade at shelf level. This `system-upgrade-initiate` command avoids intervention during the software or firmware upgrades. The command will take single package as input to upgrade whole MaxCore system. The input package will be extracted and respective software or firmware will be sent to all upgradable devices or entities. Then the upgrade process will start in sequence to all the devices and entities in the hierarchy.

Syntax

```
#system-upgrade-initiate filename "<Absolute path>"
```

Table 3-4 Parameters of systemupgrade command

Argument	Description
Absolute path	Upgrade Package Absolute Path.

Example

```
MaxCore(shelf-1-1)#system-upgrade-initiate filename
"/root/MC_SYSTEMUPDATE-R_1.1.0.25-2.iso"
```

Sample Output

```
systemupgrade Initialized
```

Update initiated successfully. System may go for multiple reboots and this takes long time.

If connected, please use status command to get the current state of the update

3.4.1 system-upgrade-status

The `system-upgrade-status` CLI command allows user to check the status of ongoing upgrade at shelf level.

Syntax

```
#system-upgrade-status
```

Example

```
MaxCore(shelf-1-1)#system-upgrade-status
```

Sample Output

```
MaxCore(shelf-1-1)#system-upgrade-status
```

```
=====
```

```
Shelf# 1                status: Upgrade In Progress
```

```
=====
```

```
Slot# 1
```

```
CPU# 1  status: Upgrade In Progress
```

```
-----  
Entity      Status      Curr Ver      Last Updated  
-----  
BMC_Application Upgrade Not Required 1.8.000000 Wed Mar 08 06:16:22  
IST 2017  
  
BMC_CPLD_Companion Upgrade Not Required 0.03.03000000 Wed Mar 08  
06:16:22 IST 2017  
  
BMC_CPLD_Glue Upgrade Not Required 0.03.00000000 Wed Mar 08 06:16:22  
IST 2017  
  
BMC_CPLD_I/O_Module Upgrade Not Required 0.06.01000000 Wed Mar 08  
06:16:22 IST 2017  
  
Basic_Board_Services Upgrade Not Required 0.3.3 Wed Mar 08 06:16:22  
IST 2017  
  
System_Services_Framework Upgrade In Progress 1.1.0.28 Wed Mar 08  
06:16:27 IST 2017  
  
PCIe-7210_BIOS Upgrade Not Required 2.1.00000005 Wed Mar 08 06:16:22  
IST 2017  
  
PCIe-7210_CPLD Upgrade Not Required 01.05.03 Wed Mar 08 06:16:22 IST  
2017  
  
ViewCheck Upgrade Pending 1.1.0.14 Wed Mar 08 06:16:22 IST 2017  
  
CPU# 2 status:--  
-----
```

```
Entity      Status      Curr Ver      Last Updated  
-----  
  
Slot# 2  
  
Slot# 3  
  
Slot# 4
```

Slot# 5
 Slot# 6
 Slot# 7
 Slot# 8
 Slot# 9
 Slot# 10
 Slot# 11
 Slot# 12
 Slot# 13
 Slot# 14
 Slot# 15

MaxCore(shelf-1-1)#system-upgrade-status

=====

Shelf# 1status: Upgrade Success

=====

Slot# 1

CPU# 1 status: Upgrade Success

Entity	Status	Curr Ver	Last Updated
BMC_Application IST 2017	--	1.8.000000	Wed Mar 08 06:12:40
BMC_CPLD_Companion IST 2017	--	0.03.03000000	Wed Mar 08 06:12:40

```
BMC_CPLD_Glue      --      0.03.00000000      Wed Mar 08 06:12:40
IST 2017

BMC_CPLD_I/O_Module  --      0.06.01000000      Wed Mar 08 06:12:40
IST 2017

Basic_Board_Services  -- 0.3.3      Wed Mar 08 06:12:40
IST 2017

System_Services_Framework  Upgrade Success 1.1.0.29 Wed Mar 08
06:18:41 IST 2017

PCIE-7210_BIOS      --      2.1.00000005      Wed Mar 08 06:12:40
IST 2017

PCIE-7210_CPLD      --      01.05.03      Wed Mar 08 06:12:40
IST 2017

ViewCheck      Upgrade Success 1.1.0.15      Wed Mar 08 06:18:55
IST 2017

CPU# 2  status:      --
```

Entity	Status	Curr Ver	Last Updated
Slot# 2			
Slot# 3			
Slot# 4			
Slot# 5			
Slot# 6			
Slot# 7			
Slot# 8			
Slot# 9			

```
Slot# 10  
Slot# 11  
Slot# 12  
Slot# 13  
Slot# 14  
Slot# 15  
MaxCore(shelf-1-1)#
```


Hardware Platform Manager Commands

Hardware Platform Manager (HPM) is used to view and configure the MaxCore™ MC3000 platform. It allows you to choose shelf host, associate disks and USBs among all the CPUs available in slot 1 and slot 15, and lets you set and get the values of BIOS boot parameters of a CPU present in any slot (1 to 15) in the system. Following are the list of HPM commands.

- *applyPEXConfiguration*
- *assignIODeviceFunctionToCPU*
- *createIODeviceFunctions*
- *destroyAllIODeviceFunctions*
- *eventLog*
- *getCPUAssignedFunctions*
- *getCPUVirtualNICFunctionCount*
- *getChassisPayloadPowerPolicy*
- *getCoolingPolicy*
- *getFunctionAssignedCPUAddress*
- *getPEXMode*
- *getSATAAssignment*
- *getShelfHostAddress*
- *getUSBAssignment*
- *getZoneType*
- *listAlarms*
- *listAvailableCPUs*
- *listAvailableIODevicees*
- *listShelfInfo*
- *removeIODeviceFunctionFromCPU*
- *resetPEXConfiguration*
- *setCPUVirtualNICFunctionCount*
- *setChassisPayloadPowerPolicy*

- *setCoolingPolicy*
- *setPEXMode*
- *setSATAAssignment*
- *setUSBAssignment*
- *getBIOSBootOrder*
- *getBIOSConsoleRedirectionParameters*
- *getBIOSBootConfiguration*
- *getBIOSPeripheralConfiguration*
- *getBIOSIIIOConfiguration*
- *getBIOSSATAConfiguration*
- *getBIOSVideoConfiguration*
- *getBIOSUSBConfiguration*
- *getBIOSProcessorConfiguration*
- *getBIOSPowerManagementConfiguration*
- *getBIOSThermalConfiguration*
- *getBIOSMemoryConfiguration*
- *getBIOSCommonRefcodeConfiguration*
- *setBIOSBootOrderNew*
- *setBIOSConsoleRedirectionParameters*
- *setBIOSBootConfiguration*
- *setBIOSPeripheralConfiguration*
- *setBIOSIIIOConfiguration*
- *setBIOSSATAConfiguration*
- *setBIOSVideoConfiguration*
- *setBIOSUSBConfiguration*
- *setBIOSProcessorConfiguration*

- *setBIOSPowerManagementConfiguration*
- *setBIOSThermalConfiguration*
- *setBIOSMemoryConfiguration*
- *setBIOSCommonRefcodeConfiguration*
- *powerOffAllApplicationCPUs*
- *setShelfAddress*
- *getShelfAddress*
- *setBMCIPAddress*
- *getBMCIPAddress*
- *listShelves*
- *addShelf*
- *removeShelf*
- *modifyShelf*
- *setSsfHostInterfaceName*
- *getSsfHostInterfaceName*
- *setDefaultConfiguration*
- *getDiscoveryStatus*
- *setPXEBootEnvironmentForCPU*
- *getPXEBootConfigurationForCPU*

NOTICE

All the commands for changing BIOS boot parameters, requires a power cycle of the system for the changes to take effect.

To execute the HPM commands, you should enter into the privilege mode of CLI as shown below:

```
[root@abts-ap-static-214 ~]# telnet localhost 11001

Trying ::1...

telnet: connect to address ::1: Connection refused

Trying 127.0.0.1...

Connected to localhost.

Escape character is '^]'.

Welcome to SSF CLI

Username: Admin

Password:

Access granted

>enable

#configure terminal

MaxCore(config)# HardwarePlatformManager
```

4.1 applyPEXConfiguration

Applies the PEX configuration provided by user. It restarts PEX and power cycles PCIE slots. Then it runs the configuration software on the Baseboard Management Controller (BMC).

NOTICE

Before applying configuration, shutdown all application CPUs because system will go for power cycle. For more details, refer section [powerOffAllApplicationCPUs](#).

Syntax

```
#applyPEXConfiguration rackID <Rack number> ShelfID <Shelf number>
```

Table 4-1 Parameters of applyPEXConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis

4.2 assignIODeviceFunctionToCPU

Assigns the function of an I/O device to the PCI tree of a CPU.

Syntax

```
#assignIODeviceFunctionToCPU cpuAddress <CPU address> rackID <Rack number> ShelfID <Shelf number> vfLocation <Virtual Function Location>
```

Table 4-2 Parameters of assignIODeviceFunctionToCPU

Argument	Description
CPU address	Location of CPU comprising shelf ID, slot ID, CPU ID and rootport number. For example, shelf x, slot x, CPU x, rootport x
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Virtual Function Location	Location of virtual function comprising shelf ID, slot ID, device number, function number. For example, shelf x, slot x, device x, and vf x

4.3 createIODeviceFunctions

Creates device functions specified by `functionCount`.

Syntax

```
#createIODeviceFunctions device address< IO device address>
functionCount <number of device functions> rackID <Rack number>
ShelfID <Shelf number>
```

Table 4-3 Parameters of createIODeviceFunctions

Argument	Description
IO device address	Device address comprising shelf id, slot id, device id. For example, shelf x, slot y, device z.
number of device functions	The number of device functions to be created for the device.
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.4 destroyAllIODeviceFunctions

Destroys all the IO device functions.

Syntax

```
#destroyAllIODeviceFunctions deviceAddress <IO device address>
rackID <Rack number> ShelfID <Shelf number>
```

Table 4-4 Parameters of destroyAllIODeviceFunctions

Argument	Description
IO device address	Device address comprising shelf id, slot id, device id. For example, shelf x, slot y, device z.
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.5 eventLog

Gets the list of events available in the MaxCore.

Syntax

```
#eventLog rackID <Rack number> ShelfID <Shelf number>
```

Table 4-5 Parameters of eventLog

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.6 getCPUAssignedFunctions

Gets the functions assigned to the PCI tree of CPU.

Syntax

```
#getCPUAssignedFunctions rackID <Rack number> ShelfID <Shelf number> slotID <physical slot number> cpuID <CPU number> rootPortNumber <root port number> [mode <running or updated configuration>]
```

Table 4-6 Parameters of getCPUAssignedFunctions

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
physical slot number	Physical slot number of target CPU.
CPU number	CPU number.
root port number	Root port number of target CPU.
configuration mode	running or updated configuration.

4.7 getCPUVirtualNICFunctionCount

Gets the number of virtual NIC functions of a CPU located by its address (slot number, CPU number).

Syntax

```
#getCPUVirtualNICFunctionCount cpuAddress <CPU address> rackID
<Rack number> ShelfID <Shelf number>
```

Table 4-7 Parameters of getCPUVirtualNICFunctionCount

Argument	Description
CPU address	Location of CPU comprising shelf ID, slot ID, CPU ID and rootport number. For example, shelf x, slot x, CPU x, rootport x.
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.8 getChassisPayloadPowerPolicy

Gets chassis power policy for a shelf. Payload power on/off.

Syntax

```
#getChassisPayloadPowerPolicy rackID <Rack number> ShelfID <Shelf
number>
```

Table 4-8 Parameters of getChassisPayloadPowerPolicy

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.9 getCoolingPolicy

Gets the shelf cooling policy - low noise or high reliability.

Syntax

```
#getCoolingPolicy rackID <Rack number> ShelfID <Shelf number>
```

Table 4-9 Parameters of getCoolingPolicy

Argument	Description
CPU address	Location of CPU comprising shelf ID, slot ID, CPU ID and rootport number. For example, shelf x, slot x, CPU x, rootport x
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.10 getFunctionAssignedCPUAddress

Gets the CPU address to which the Virtual Function (VF) is assigned.

Syntax

```
#getFunctionAssignedCPUAddress Rack ID <Rack number> ShelfID <Shelf number> vfLocation <virtual function location>
```

Table 4-10 Parameters of getFunctionAssignedCPUAddress

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
virtual function location	Location of virtual function comprising shelf ID, slot ID, device number, function number. For example, shelf x, slot x, device x, vf x

4.11 getPEXMode

Gets PEX mode to basic or express fabric mode.

Syntax

```
#getPEXMode rackID <Rack number> ShelfID <Shelf number>
```

Table 4-11 Parameters of getPEXMode

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.12 getSATAAssignment

Gets SATA assignment to shelf hosts. For example, SATA 1 and 2 assigned to slot 1, cpu 1 SATA 3 and 4 assigned to slot 1, cpu 2.

Syntax

```
#getSATAAssignment rackID <Rack number> ShelfID <Shelf number>
```

Table 4-12 Parameters of getSATAAssignment

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.13 getShelfHostAddress

Gets the address of shelf host (slot number, CPU number).

Syntax

```
#getShelfHostAddress rackID <Rack number> ShelfID <Shelf number>
```

Table 4-13 Parameters of getShelfHostAddress

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.14 getUSBAssignment

Gets USB assignment of shelf slots.

Syntax

```
#getUSBAssignment rackID <Rack number> ShelfID <Shelf number>
```

Table 4-14 Parameters of getUSBAssignment

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.15 getZoneType

Gets the zone type - host or downstream.

Syntax

```
#getZoneType rackID <Rack number> ShelfID <Shelf number> slotID  
<slot number>
```

Table 4-15 Parameters of getZoneType

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
slot number	Displays physical slot number.

4.16 listAlarms

Lists of alarms - Critical/Major/Minor.

Syntax

```
#getUSBAssignment rackID <Rack number> ShelfID <Shelf number>
```

Table 4-16 Parameters of listAlarms

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.17 listAvailableCPUs

Provides list of all the available CPUs in the MaxCore.

Syntax

```
#listAvailableCPU rackID <Rack number> ShelfID <Shelf number>
```

Table 4-17 Parameters of listAvailableCPUs

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.18 listAvailableIODevices

Provides list the available IO devices in the MaxCore.

Syntax

```
#listAvailableIODevices rackID <Rack number> ShelfID <Shelf number>
```

Table 4-18 Parameters of listAvailableIODevices

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.19 listShelfInfo

Lists info of all the available shelves/MaxCore in the system.

Syntax

```
#listShelfInfo rackID <Rack number> ShelfID <Shelf number>
```

Table 4-19 Parameters of listShelfInfo

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.20 removeIODeviceFunctionFromCPU

Removes the function of an I/O device from the PCI tree of a CPU.

Syntax

```
#removeIODeviceFunctionFromCPU cpuAddress <cpu address> rackID  
<Rack number> ShelfID <Shelf number> vfLocation <virtual function>
```

Table 4-20 Parameters of removeIODeviceFunctionFromCPU

Argument	Description
CPU address	Location of CPU comprising shelf ID, slot ID, CPU ID and rootport number. For example, shelf x, slot x, CPU x, rootport x
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
virtual function location	Location of virtual function comprising shelf ID, slot ID, device number, function number. For example, shelf x, slot x, device x, vf x

4.21 resetPEXConfiguration

This method resets the PEX configuration to last running configuration.

Syntax

```
#resetPEXConfiguration rackID <Rack number> ShelfID <Shelf number>
```

Table 4-21 Parameters of resetPEXConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.22 setCPUVirtualNICFunctionCount

Sets the number of virtual NIC functions of a CPU located by its address (slot number, CPU number).

Syntax

```
#setCPUVirtualNICFunctionCount cpuAddress <cpu address>
functionCount <virtual function> rackID <Rack number> ShelfID
<Shelf number>
```

Table 4-22 Parameters of setCPUVirtualNICFunctionCount

Argument	Description
CPU address	Location of CPU comprising shelf ID, slot ID, CPU ID and rootport number. For example, shelf x, slot x, CPU x, rootport x
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
function count	Virtual NIC function count.

4.23 setChassisPayloadPowerPolicy

Sets chassis power policy for a shelf. Power on/off payload.

Syntax

```
#setChassisPayloadPowerPolicy chassisPowerPolicy <chassis Power Policy> rackID <rack number> shelfID <shelf number>
```

Table 4-23 Parameters of removeIODeviceFunctionFromCPU

Argument	Description
chassis Power Policy	Set power policy for a shelf. Power on/off payload when the shelf is powered on.
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.24 setCoolingPolicy

Sets the shelf cooling policy.

Syntax

```
#setCoolingPolicy coolingPolicy <cooling policy> rackID <Rack number> ShelfID <Shelf number>
```

Table 4-24 Parameters of setCoolingPolicy

Argument	Description
cooling policy	Cooling policy of a shelf - high reliability or low noise
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.25 setPEXMode

Sets PEX mode to basic or express fabric mode.

Syntax

```
#setPEXMode mode <PEX mode> rackID <Rack number> ShelfID <Shelf number>
```

Table 4-25 Parameters of setPEXMode

Argument	Description
mode	PEX mode - base mode or express fabric mode.
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.

4.26 setSATAAssignment

Sets SATA assignment to shelf hosts. For example: SATA 1 and 2 assigned to slot 1, CPU 1 SATA 3 and 4 assigned to slot 1, CPU 2.

Syntax

```
#setSATAAssignment rackID <Rack number> sataAssignment <sata assignment> ShelfID <Shelf number>
```

Table 4-26 Parameters of setSATAAssignment

Argument	Description
Rack number	Rack number of the target chassis.
sata assignment	SATA assignment for slot 1/15 comprising the CPU addresses and disk numbers. For example, {slot 1,cpu 2,disk 4};{slot 15,cpu 1,disk 1};{slot 1,cpu 2,disk 2};{slot 15,cpu 1,disk 3};
Shelf number	Shelf number of the target chassis.

4.27 setUSBAssignment

Sets USB assignment of shelf slots.

Syntax

```
#setUSBAssignment rackID <Rack number> ShelfID <Shelf number>
usbAssignment <USB assignment>
```

Table 4-27 Parameters of setUSBAssignment

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
USB assignment	USB assigned CPU addresses separated by commas. For example, Each USB Assignment entry is as follows - (Slot X, CPU Y, USB Z)

4.28 getBIOSBootOrder

Gets the value of BIOS boot parameters related to boot order configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#getBIOSBootOrder rackID <Rack number> shelfID <Shelf number>
slotID <Slot number> cpuID <CPU number>
```

Table 4-28 Parameters of getBIOSBootOrder

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.

4.29 getBIOSConsoleRedirectionParameters

Gets the value of BIOS boot parameters related to Console Redirection of CPU located by its address (slot number, CPU number).

Syntax

```
#getBIOSConsoleRedirectionParameters rackID <Rack number> shelfID
<Shelf number> slotID <Slot number> cpuID <CPU number>
```

Table 4-29 Parameters of getBIOSConsoleRedirectionParameters

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.

4.30 getBIOSBootConfiguration

Gets the value of BIOS boot parameters related to Boot Configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#getBIOSBootConfiguration rackID <Rack number> shelfID <Shelf
number> slotID <Slot number> cpuID <CPU number>
```

Table 4-30 Parameters of getBIOSBootConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.

4.31 getBIOSPeripheralConfiguration

Gets the value of BIOS boot parameters related to Peripheral configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#getBIOSPeripheralConfiguration rackID <Rack number> shelfID <Shelf number> slotID <Slot number> cpuID <CPU number>
```

Table 4-31 Parameters of getBIOSPeripheralConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.

4.32 getBIOSIIConfiguration

Gets the value of BIOS boot parameters related to IIO configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#getBIOSIIConfiguration rackID <Rack number> shelfID <Shelf number> slotID <Slot number> cpuID <CPU number>
```

Table 4-32 Parameters of getBIOSIIConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.

4.33 getBIOSATAConfiguration

Gets the value of BIOS boot parameters related to PCH SATA configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#getBIOSSATAConfiguration rackID <Rack number> shelfID <Shelf number> slotID <Slot number> cpuID <CPU number>
```

Table 4-33 Parameters of getBIOSSATAConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.

4.34 getBIOSVideoConfiguration

Gets the value of BIOS boot parameters related to Video configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#getBIOSVideoConfiguration rackID <Rack number> shelfID <Shelf number> slotID <Slot number> cpuID <CPU number>
```

Table 4-34 Parameters of getBIOSVideoConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.

4.35 getBIOSUSBConfiguration

Gets the value of BIOS boot parameters related to USB configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#getBIOSUSBConfiguration rackID <Rack number> shelfID <Shelf
number> slotID <Slot number> cpuID <CPU number>
```

Table 4-35 Parameters of getBIOSUSBConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.

4.36 getBIOSProcessorConfiguration

Gets the value of BIOS boot parameters related to Processor configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#getBIOSProcessorConfiguration rackID <Rack number> shelfID <Shelf
number> slotID <Slot number> cpuID <CPU number>
```

Table 4-36 Parameters of getBIOSProcessorConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.

4.37 getBIOSPowerManagementConfiguration

Gets the value of BIOS boot parameters related to Power Management configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#getBIOSPowerManagementConfiguration rackID <Rack number> shelfID
<Shelf number> slotID <Slot number> cpuID <CPU number>
```

Table 4-37 Parameters of getBIOSPowerManagementConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.

4.38 getBIOSThermalConfiguration

Gets the value of BIOS boot parameters related to Thermal Configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#getBIOSThermalConfiguration rackID <Rack number> shelfID <Shelf
number> slotID <Slot number> cpuID <CPU number>
```

Table 4-38 Parameters of getBIOSThermalConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.

4.39 getBIOSMemoryConfiguration

Gets the value of BIOS boot parameters related to Memory Configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#getBIOSMemoryConfiguration rackID <Rack number> shelfID <Shelf
number> slotID <Slot number> cpuID <CPU number>
```

Table 4-39 Parameters of getBIOSMemoryConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.

4.40 getBIOSCommonRefcodeConfiguration

Gets the value of BIOS boot parameters related to Common Refcode Configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#getBIOSCommonRefcodeConfiguration rackID <Rack number> shelfID
<Shelf number> slotID <Slot number> cpuID <CPU number>
```

Table 4-40 Parameters of getBIOSCommonRefcodeConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.

4.41 setBIOSBootOrderNew

Replaces the current boot order configuration with the fresh one of CPU located by its address (slot number, CPU number).

Syntax

```
#setBIOSBootOrderNew rackID <Rack number> shelfID <Shelf number>
slotID <Slot number> cpuID <CPU number> BootOrder <Boot Order>
```

Table 4-41 Parameters of setBIOSBootOrderNew

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.
BootOrder	Boot Order: Boot Order: [< bootdev > [[, < bootdev >]]] bootdev= full name of a boot option, as it is shown by the BIOS, or one of the following predefined selfspeaking names: {sdcard/efisdcard/bpusb/bpusb0/bpusb1/bpusb2/bpusb3/efibpusb/efibpusb0/efibpusb1/efibpusb2/efibpusb3/iomusb/iomusb0/iomusb1/iomusb2/iomusb3/efiiomusb/efiiomusb0/efiiomusb1/efiiomusb2/efiiomusb3/iomsata0/iomsata1/efiiomsata0/efiiomsata1/efishell} For example, sdcard,efisdcard.
Result	Value of the selected parameter.

Note: When configuring boot order for an EFI boot device, mention the full name of the boot option (as it is shown by the BIOS) in the `BootOrder` argument. For example,

```
#setBIOSBootOrderNew rackID 1 shelfID 1 slotID 1 cpuID 1 BootOrder
"EFI Net 0 IPv4 (02-0B-00-10-02-02),sdcard".
```

4.42 setBIOSBootOrderDefault

Sets the boot order configuration back to default of CPU located by its address (slot number, CPU number).

Syntax

```
#setBIOSBootOrderDefault rackID <Rack number> shelfID <Shelf
number> slotID <Slot number> cpuID <CPU number>
```

Table 4-42 Parameters of setBIOSBootOrderDefault

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.
Result	Value of the selected parameter.

4.43 setBIOSBootOrderbyIndex

Modifies the existing boot order configuration according to index and boot device provided of CPU located by its address (slot number, CPU number).

Syntax

```
#setBIOSBootOrderbyIndex rackID <Rack number> shelfID <Shelf
number> slotID <Slot number> cpuID <CPU number> BootDevice <Boot
Device> Index <Index>
```

Table 4-43 Parameters of setBIOSBootOrderbyIndex

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.

Table 4-43 Parameters of setBIOSBootOrderbyIndex (continued)

Argument	Description
Boot Device	Boot Device: full name of a boot option, as it is shown by the BIOS, or one of the following predefined selfspeaking names: {sdcard/efisdcard/bpusb/bpusb0/bpusb1/bpusb2/bpusb3/efibpusb/efibpusb0/efibpusb1/efibpusb2/efibpusb3/iomusb/iomusb0/iomusb1/iomusb2/iomusb3/efiiomusb/efiiomusb0/efiiomusb1/efiiomusb2/efiiomusb3/iomsata0/iomsata1/efiiomsata0/efiiomsata1/efishell}
Index	Number representing position in boot order. Possible values are 1,2,3 etc. Lower number represents higher priority.
Result	Value of the selected parameter.

Note: When configuring boot order for an EFI boot device, mention the full name of the boot option (as it is shown by the BIOS) in the `BootDevice` argument. For example,
`#setBIOSBootOrderNew rackID 1 shelfID 1 slotID 1 cpuID 1 Index 1 BootDevice "EFI Net 0 IPv4 (02-0B-00-10-02-02)".`

4.44 setBIOSConsoleRedirectionParameters

Sets the value of BIOS boot parameters related to Console Redirection of CPU located by its address (slot number, CPU number).

Syntax

```
#setBIOSConsoleRedirectionParameters rackID <Rack number> shelfID
<Shelf number> slotID <Slot number> cpuID <CPU number> BaudRate
<Baud Rate>
```

Table 4-44 Parameters of setBIOSConsoleRedirectionParameters

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.

Table 4-44 Parameters of *setBIOSConsoleRedirectionParameters*

Argument	Description
CPU number	CPU number.
BaudRate	Baud Rate: 9600(0), 19200(1), 38400(2), 57600(3), 115200(4).

4.45 setBIOSBootConfiguration

Sets the value of BIOS boot parameters related to Boot Configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#setBIOSBootConfiguration rackID <Rack number> shelfID <Shelf
number> slotID <Slot number> cpuID <CPU number> SkipShell <Skip
Shell> AutoReset <Auto Reset> BootType <Boot Type> NetworkStack
<Network Stack> PXEBootCapability <PXE Boot Capability> USBBoot
<USB boot>
```

Table 4-45 Parameters of *setBIOSBootConfiguration*

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.
SkipShell	Skip Internal EFI Shell: OFF(1), ON(0).
AutoReset	Auto Reset: OFF(1), ON(0).
BootType	Boot Type: dual(0), legacy(1), uefi(2).
NetworkStack	Network Stack: OFF(1), ON(0).
PXEBootCapability	PXE Boot Capability: ipv4(0), ipv6(1), ipv4v6(2).
USBBoot	USB Boot: OFF(1), ON(0).

4.46 setBIOSPeripheralConfiguration

Sets the value of BIOS boot parameters related to Peripheral configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#setBIOSPeripheralConfiguration rackID <Rack number> shelfID <Shelf number> slotID <Slot number> cpuID <CPU number> PCIeSRIOV <PCIe SR-IOV> PCIeARI <PCIe ARI> Pci64bitDecode <Pci 64-bit Decode> SpreadSpectrum <Spread Spectrum>
```

Table 4-46 Parameters of setBIOSPeripheralConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.
PCIeSRIOV	PCIe SR-IOV: OFF(1), ON(0).
PCIeARI	PCIe ARI: OFF(1), ON(0).
Pci64bitDecode	Pci 64-bit Decode: OFF(1), ON(0).
SpreadSpectrum	Spread Spectrum: OFF(1), ON(0).
Result	Result of the operation.

4.47 setBIOSIIIOConfiguration

Sets the value of BIOS boot parameters related to IIO configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#setBIOSIIOConfiguration rackID <Rack number> shelfID <Shelf
number> slotID <Slot number> cpuID <CPU number> VTd <VT d>
InterruptRemapping <Interrupt Remapping>
```

Table 4-47 Parameters of setBIOSIIOConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.
VTd	Intel VT for Directed I/O (VT-d): OFF(1), ON(0).
InterruptRemapping	Interrupt Remapping: OFF(1), ON(0).
Result	Result of the operation.

4.48 setBIOSSATAConfiguration

Sets the value of BIOS boot parameters related to PCH SATA configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#setBIOSSATAConfiguration rackID <Rack number> shelfID <Shelf
number> slotID <Slot number> cpuID <CPU number> SATAController <SATA
Controller> SATAMode <SATA Mode> RAIDOROMdelay <RAID OROM delay>
ALPMSupport <ALPM Support> SATASpeed <SATA Speed>
```

Table 4-48 Parameters of setBIOSSATAConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.

Table 4-48 Parameters of setBIOSATAConfiguration

Argument	Description
SATAController	SATA Controller: OFF(1), ON(0).
SATAMode	HDC configured as (SATA Mode Selection): ide(0), ahci(1), raid(2).
RAIDOROMdelay	RAID OROM prompt delay (in sec): 2(0), 4(1), 6(2).
ALPMSupport	Aggressive LPM Support: OFF(1), ON(0).
SATASpeed	SATA Speed Support (in Gb/s): 1.5(0), 3(1), 6(2).
Result	Result of the operation.

4.49 setBIOSVideoConfiguration

Sets the value of BIOS boot parameters related to Video configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#setBIOSVideoConfiguration rackID <Rack number> shelfID <Shelf number> slotID <Slot number> cpuID <CPU number> DisplayMode <Display Mode>
```

Table 4-49 Parameters of getBIOSVideoConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.
DisplayMode	Display Mode: usual(0), ignoreoromio[Ignore VGA Option ROM and I/O Space](1).
Result	Result of the operation.

4.50 setBIOSUSBConfiguration

Sets the value of BIOS boot parameters related to USB configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#setBIOSUSBConfiguration rackID <Rack number> shelfID <Shelf number> slotID <Slot number> cpuID <CPU number> USBBIOSSupport <USB BIOS Support> UsbPort0 <Usb port0,1,2...7>
```

Table 4-50 Parameters of setBIOSUSBConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.
USBBIOSSupport	USB BIOS Support: OFF(1), ON(0).
UsbPort0	USB Port 0: OFF(1), ON(0).
UsbPort1	USB Port 1: OFF(1), ON(0).
UsbPort2	USB Port 2: OFF(1), ON(0).
UsbPort3	USB Port 3: OFF(1), ON(0).
UsbPort4	USB Port 4: OFF(1), ON(0).
UsbPort5	USB Port 5: OFF(1), ON(0).
UsbPort6	USB Port 6: OFF(1), ON(0).
UsbPort7	USB Port 7: OFF(1), ON(0).
Result	Result of the operation.

4.51 setBIOSProcessorConfiguration

Sets the value of BIOS boot parameters related to Processor configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#setBIOSProcessorConfiguration rackID <Rack number> shelfID <Shelf
number> slotID <Slot number> cpuID <CPU number> HyperThreading
<Hyper Threading> PerformanceWatt <Performance Watt>
ExecuteDisableBit <ExecuteDisableBit> EnableLTSX <Enable LTSX> VMX
<VMX> HardwarePrefetcher <HardwarePrefetcher> AdjCachePrefetch
<AdjCachePrefetch> DCA <DCA> X2APIC <X2APIC>
```

Table 4-51 Parameters of setBIOSProcessorConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.
HyperThreading	Hyper-Threading [ALL]: OFF(1), ON(0).
PerformanceWatt	Performance/Watt: Traditional(0), Power Optimized(1).
ExecuteDisableBit	Execute Disable Bit: OFF(1), ON(0).
EnableLTSX	Enable LTSX: OFF(1), ON(0).
VMX	VMX: OFF(1), ON(0).
HardwarePrefetcher	Hardware Prefetcher: OFF(1), ON(0).
AdjCachePrefetch	Adjacent Cache Prefetch: OFF(1), ON(0).
DCA	Direct Cache Access: OFF(0), ON(1), AUTO(2).
X2APIC	X2APIC: OFF(1), ON(0).
Result	Result of the operation.

4.52 setBIOSPowerManagementConfiguration

Sets the value of BIOS boot parameters related to Power Management configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#setBIOSPowerManagementConfiguration rackID <Rack number> shelfID
<Shelf number> slotID <Slot number> cpuID <CPU number> EIST <EIST>
TurboMode <Turbo Mode> CPUCState <CPU C State> PackageCStatelimit
<Package C State limit> CPUC3report <CPU C3 report> CPUC6report <CPU
C6 report> EnhancedHaltState <Enhanced Halt State> OSACPICx <OS ACPI
Cx>
```

Table 4-52 Parameters of setBIOSPowerManagementConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.
EIST	EIST (GV3): OFF(1), ON(0).
TurboMode	Turbo Mode: OFF(1), ON(0).
CPUCState	CPU C State: OFF(1), ON(0).
PackageCStatelimit	Package C State limit: c0c1(0), c2(1), c6nr(2).
CPUC3report	CPU C3 report: OFF(1), ON(0).
CPUC6report	CPU C6 report: OFF(1), ON(0).
EnhancedHaltState	Enhanced Halt State (C1E): OFF(1), ON(0).
OSACPICx	OS ACPI Cx: c2(0), c3(1).
Result	Result of the operation.

4.53 setBIOSThermalConfiguration

Sets the value of BIOS boot parameters related to Thermal Configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#setBIOSThermalConfiguration rackID <Rack number> shelfID <Shelf number> slotID <Slot number> cpuID <CPU number> DTS <DTS>
```

Table 4-53 Parameters of setBIOSThermalConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.
DTS	DTS: OFF(1), ON(0).
Result	Result of the operation.

4.54 setBIOSMemoryConfiguration

Sets the value of BIOS boot parameters related to Memory Configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#setBIOSMemoryConfiguration rackID <Rack number> shelfID <Shelf number> slotID <Slot number> cpuID <CPU number> MemoryFrequency <Memory Frequency> HaltOnMemTrainError <Halt on mem Training Error>
```

Table 4-54 Parameters of setBIOSMemoryConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.
MemoryFrequency	Memory Frequency: auto(0), 1333(1), 1600(2), 1867(3), 2133(4).
HaltOnMemTrainError	Halt on mem Training Error: OFF(1), ON(0).

Table 4-54 Parameters of setBIOSMemoryConfiguration

Argument	Description
Result	Result of the operation.

4.55 setBIOSCommonRefcodeConfiguration

Sets the value of BIOS boot parameters related to Common Refcode Configuration of CPU located by its address (slot number, CPU number).

Syntax

```
#setBIOSCommonRefcodeConfiguration rackID <Rack number> shelfID
<Shelf number> slotID <Slot number> cpuID <CPU number> Numa <Numa>
```

Table 4-55 Parameters of setBIOSCommonRefcodeConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.
Numa	Numa: OFF(1), ON(0).
Result	Result of the operation.

4.56 powerOffAllApplicationCPUs

It will initiate the graceful shutdown or poweroff all application CPUs.

Syntax

```
#powerOffAllApplicationCPUs rackID <Rack number> shelfID <Shelf
number> powerDown <Power> IncludeNetworkCPUs <Network CPUs> whence
<whence>
```

Table 4-56 Parameters of powerOffAllApplicationCPUs

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
IncludeNetworkCPUs	Include network CPUs like 9205 or not for power off. FALSE (o) or TRUE(1).
whence	If “atonce”, power for CPU is set immediately. If “atstart”, given power for CPU is applied at the start of Shelf Host. atonce (o) or atstart (1).
PowerDown	HARD_POWER_DOWN(0) or GRACEFUL_POWER_DOWN(1).
result	Result of the operation.

4.57 setShelfAddress

It sets the new Shelf address, it contains new Shelf Name and ShelfId.

NOTICE

Before changing shelfId, you need to shutdown all application CPUs because system will go for power cycle. Shelf name changes is not required for shutdown of application CPUs. For more details, refer section [powerOffAllApplicationCPUs](#).

Syntax

```
#setShelfAddress rackID <Rack number> currentShelfID <Current shelf
number> newShelfID <New shelf number> shelfName <New shelf name>
```

Table 4-57 Parameters of setShelfAddress

Argument	Description
Rack number	Rack number of the target chassis.
Current Shelf number	Current ShelfID
New shelf number	Provide the new ShelfID, its Range:1-255.
New shelf name	Provide the shelf name.
result	Result of the operation.

4.58 getShelfAddress

It gets the Shelf address of required shelf, it contains name of Shelf and Shelfid.

Syntax

```
#getShelfAddress rackID <Rack number> shelfID <Shelf number>
```

Table 4-58 Parameters of getShelfAddress

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
result	Result of the operation.

4.59 setBMCIPAddress

It will set the BMC IP Address, it contains BMC IP, Subnet Mask, Gateway IP.

Syntax

```
#setBMCIPAddress rackID <Rack number> shelfID <Shelf number>
DHCPConfiguration <DHCP Configuration> BmcIPAddr <BMC IP Address>
GatewayIPAddr <Gateway IP Address> SubnetMask <Subnet Mask>
```

Table 4-59 Parameters of setBMCIPAddress

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
DHCP Configuration	DHCP Configuration: DISABLE (0) / ENABLE (1).
BMC IP Address	Provide the BMCIPAddr to set.
Gateway IP Address	Provide the Gateway IP to set.
Subnet Mask	Provide the SubnetMask to set.
result	Result of the operation.

4.60 getBMCIPAddress

It gets the BMC IP Address, it contains BMC IP, Subnet Mask, Gateway IP and DHCP configuration.

Syntax

```
#getBMCIPAddress rackID <Rack number> shelfID <Shelf number>
```

Table 4-60 Parameters of getBMCIPAddress

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
result	Result of the operation.

4.61 listShelves

It provides the list of all configured shelf in `maxcore.conf`.

Syntax

```
#listShelves
```

4.62 addShelf

It configures the new shelf for Multishelf.

Note: You need to Restart the ssfCore using `systemctl restart ssfCore.service` to effect the changes.

Syntax

```
#addShelf shelfID <Shelf number> shelfHostIpAddr <Shelf Host IP Address> master <master> shelfName <New shelf name>
```

Table 4-61 Parameters of addShelf

Argument	Description
Shelf number	Shelf number of the new shelf.
Shelf Host IP Address	ShelfHost IP address of new Shelf on which SsfCore can connect.
master	Whether configured shelf is a master or a slave, for master "true" and for slave "false".
New shelf name	Provide ShelfName of the new shelf. Default name is "Shelf". Note: Shelf Name limit is 16 characters.
result	Result of the operation.

4.63 removeShelf

It removes the configured shelf.

Note: You need to restart the ssfCore using `systemctl restart ssfCore.service` to effect the changes.

Syntax

```
#removeShelf shelfID <Shelf number>
```

Table 4-62 Parameters of removeShelf

Argument	Description
Shelf number	It ShelfID of Shelf which you want to remove.
result	Result of the operation.

4.64 modifyShelf

It modifies the existing shelf data.

Note: You need to Restart the ssfCore using `systemctl restart ssfCore.service` to effect the changes.

Syntax

```
#modifyShelf currentShelfID <Current shelf number> newShelfID <New shelf number> newShelfHostIpAddr <New Shelf Host IP Address> isMaster <Master> newShelfName <New shelf name>
```

Table 4-63 Parameters of modifyShelf

Argument	Description
Current Shelf number	Current shelf number of the shelf.
New Shelf number	New shelf number of the modifiable shelf
New Shelf Host IP Address	New ShelfHost IP address of the shelf to which SsfCore can connect.
Master	Whether configured shelf is a master or a slave, for master “true” and for slave “false”.
New shelf name	New ShelfName of the shelf.
result	Result of the operation.

4.65 setSsfHostInterfaceName

It sets the local ssfHost interface name to which ssfAgent can connect.

Syntax

```
#setSsfHostInterfaceName ssfHostInterface <SSF host interface name>
```

Table 4-64 Parameters of setSsfHostInterfaceName

Argument	Description
SSF host interface name	Provide the name of local ssfHost interface name to which all ssfAgents can connect.
result	Result of the operation.

4.66 getSsfHostInterfaceName

It gets the SSF host interface name (where ssfCore is running).

Syntax

```
#getSsfHostInterfaceName
```

4.67 setDefaultConfiguration

It sets the Virtual functions, Disk and USB assignment to default.

Syntax

```
#setDefaultConfiguration rackID <Rack number> shelfID <Shelf number>
```

Table 4-65 Parameters of setDefaultConfiguration

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
result	Result of the operation.

4.68 getDiscoveryStatus

It gets the status of basic services (like ipmitool, pciemgmt), and checking if shelf id is zero or not, and also Shelf discovery status.

Syntax

```
#getDiscoveryStatus rackID <Rack number> shelfID <Shelf number>
```

Table 4-66 Parameters of getDiscoveryStatus

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
result	Result of the operation.

4.69 setPXEBootEnvironmentForCPU

It sets the configure PXE Boot for CPU. Also, it upload bootimages (kernel and ramdisk).

Syntax

```
#setPXEBootEnvironmentForCPU rackID <Rack number> shelfID <Shelf number> slotID <slot number> cpuID <CPU number> PXEBoot <Enable/Disable> uploadFile <True/False> filePath <absolute file path>
```

Table 4-67 Parameters of getDiscoveryStatus

Argument	Description
Rack number	Rack number of the target chassis.
Shelf number	Shelf number of the target chassis.
Slot number	Slot number of target CPU.
CPU number	CPU number.
PXEBoot	Enable or Disable PXE Boot Configuration for CPU.

Table 4-67 Parameters of `getDiscoveryStatus` (continued)

Argument	Description
<code>uploadFile</code>	TRUE: for Upload file and FALSE for set the PXE BOOT Environment.
<code>filePath</code>	Provide absolute file path of boot images. For example (<code>../pcie7410/filename</code>).
<code>result</code>	Result of the operation.

Note: You can use this command for uploading image set PXE Configuration and clear PXE configuration. For each operations, parameters and its values are mentioned in the below table.

Operation	PXEBoot	<code>uploadFile</code>	<code>filePath</code>
To upload the Image	DISABLE	TRUE	Absolute Filepath
To set the PXE Boot Configuration	ENABLE	FALSE	Optional
To clear the PXE Boot Configuration	DISABLE	FALSE	Optional

4.70 `getPXEBootConfigurationForCPU`

It gets the PXE Boot Configuration for CPU (like kernel and ramdisk) image available or not.

Syntax

```
#getPXEBootConfigurationForCPU rackID <Rack number> shelfID <Shelf number> slotID <slot number> cpuID <CPU number>
```

Table 4-68 Parameters of `getDiscoveryStatus`

Argument	Description
<code>Rack number</code>	Rack number of the target chassis.
<code>Shelf number</code>	Shelf number of the target chassis.
<code>Slot number</code>	Slot number of target CPU.

Table 4-68 Parameters of getDiscoveryStatus (continued)

Argument	Description
<code>CPU number</code>	CPU number.
<code>result</code>	Result of the operation.

System commands allows you to view detailed hardware and software configuration information of system. Hardware configuration details include Physical Execution Environments (PEE) and Virtual Execution Environments (VEE). Software configuration details include operating systems, services, software entities managed by VEE, and so on.

The system and its components information is displayed in the hierarchal tree structure. For example, the system information is displayed along with its child nodes, such as slots, and sites.

5.1 CLI Commands in disable mode

This section describes the CLI commands that are available in the disable mode, to enter the disable mode:

```
Trying ::1...
telnet: connect to address ::1: Connection refused

Trying 127.0.0.1...
Connected to localhost.
Escape character is '^]'.
Welcome to SSF CLI
Username: Admin
Password:
Access granted
>
```

Events display:

The `events display` command is used to enable/disable the events that are received in the current session. If the `events display` is enabled the user can see the event messages on the console.

Syntax:

```
>events display <mode>
```

For example:

```
>events display ?  
  
  disable  Disable functionality  
  enable   Enable functionality
```

set configuration:

The `set configuration` command is used to set the current configuration.

Syntax:

```
>set configuration <configuration file name>
```

The following table provides the list of Disable mode commands:

Table 5-1 Parameters of Disable mode commands

Argument	Description
actioninput	Enable or disable action input debugging
enable	Turn on privileged commands
events	Events related commands
exit	Exit from the EXEC
lexeroutput	Enable or disable lexer debug output
ping	Send echo messages
read-only-commands	Enable or disable showing commands with read-only access
reload	Reloads commands
shortcuts	Display shortcuts
show	Show running system information
telnet	Open a telnet connection
traceroute	Trace route to destination.

5.2 CLI commands in enable mode

The following procedure explains how to go to the enable mode:

```

Trying ::1...
telnet: connect to address ::1: Connection refused
Trying 127.0.0.1...
Connected to localhost.
Escape character is '^]'.
Welcome to SSF CLI

Username: Admin
Password:
Access granted

>enable

```

The following table provides the list of Enable mode commands:

Table 5-2 Parameters of Enable mode commands

Argument	Description
add	Create system object
assign	Keyword
configure	Enter configuration mode
copy	Copy a config script
debug	Configure debugging output
disable	Turn off privileged commands
event	Event configuration
exit	Exit from the EXEC
group	Keyword
halt	Shut down system
lock	Perform lock
logging	Configure logging

Table 5-2 Parameters of Enable mode commands (continued)

Argument	Description
more	Configure more
no	Negate a command or set its defaults
password	Specify the password for the user
ping	Send echo messages
remove	Keyword
shell	The shell command executes a OS command
show	Show running system information
shutdown	Shut down system
snmp-server	Configure SNMP Agent
source	Execute script
telnet	Open a telnet connection
terminal	Set terminal line parameters
traceroute	Trace route to destination
username	Establish User Name Authentication
write	Save the current configuration to NVRAM

5.3 CLI commands in config mode

The following procedure explains how enter into the config mode:

```
#Trying ::1...
telnet: connect to address ::1: Connection refused
Trying 127.0.0.1...
Connected to localhost.
Escape character is '^]'.
Welcome to SSF CLI
```

```
Username: Admin
```

```
Password:
```

```
Access granted
```

```
>enable
```

```
#configure terminal
```

CLI commands in system mode

deletelog

The `deletelog` command is used to clear the event log messages from the SSF system.

Syntax

```
#deletelog
```

eventFilterSeverity

The `eventFilterSeverity` command is used to store the logs based on the severity of events received in the system.

Event Severity is a 8 bit integer representing: 0 Disable (disable all logs), 1 Critical, 2 Major, 4 Minor, 8 Informational, 16 OK, 32 DEBUG, 255 All, It is possible to accumulate the values so that a combination of events can be filtered. Max allowed value is 255.

Syntax

```
# eventFilterSeverity <severity number>
```

eventFilterType

The `eventFilterType` command is used to store the events based on the type of the event.

Event Type is a 16 bit integer representing:

- 0 Disable (disable all logs)
- 1 SSF_EVENT_TYPE_MASK_SENSOR
- 2 SSF_EVENT_TYPE_MASK_SENSORENABLE

```
4  SSF_EVENT_TYPE_MASK_WATCHDOG
8  SSF_EVENT_TYPE_MASK_OEM
16 SSF_EVENT_TYPE_MASK_SOFTWARE
32 SSF_EVENT_TYPE_MASK_HOTSWAP
64 SSF_EVENT_TYPE_MASK_RESOURCE
128 SSF_EVENT_TYPE_MASK_DOMAIN
256 SSF_EVENT_TYPE_MASK_USER
512 SSF_EVENT_TYPE_MASK_REGISTRATION
```

It is possible to accumulate the values so that a combination of events can be filtered. Max allowed value is 1023.

Syntax

```
# eventFilterType <event type number>
```

listlog

The `listlog` command is used to show the events in the system.

Syntax

```
# listlog
```

maxNoEvents

The `maxNoEvents` command is used to store maximum of events in the system.

Syntax

```
# maxNoEvents
```

userConfig

The `userConfig` command is used to allow the user to decide whether to apply the configuration or not.

User confirmation attribute for applying heterogeneous configurations.

0 - Yes, can apply the configuration.

1 - No, Do not apply the configuration

Syntax

```
# userConfig <config attribute>
```

logfilter

The `logfilter` command allows user to configure the log sinks.

Syntax

```
# logfilter <logsink name>
```

After entering logsink say syslog, user can configure the module and priority of that logsink.

modules

```
MaxCore(logfilter-syslog)#modules ?
```

A sequence of modules names separated by comma, for instance
WEB,SYSTEM,CLI (applicable for module log filter) [empty by default]

```
MaxCore(logfilter-syslog)#priority ?
```

```
critical  Filter priority (applicable for priority log filter)
[debug]
```

```
debug     Filter priority (applicable for priority log filter)
[debug]
```

```
error     Filter priority (applicable for priority log filter)
[debug]
```

```
info      Filter priority (applicable for priority log filter)
[debug]
```

```
warning   Filter priority (applicable for priority log filter)
[debug]
```

The following table provides the list of Configure mode commands:

Table 5-3 Parameters of Configure mode commands

Argument	Description
UsingMOIDQueryNode	MOIDQueryNode is usedThe
event	The shell command executes a OS command
exit	Exit from configure mode
no	Negate a command or set its defaults
show	Show running system information
system	Configure system
logfilter	Configure logfilter

5.4 CLI Commands in System Mode

All system commands are available in system mode. To use the system commands, you need to enter into the system mode.

Syntax

```
>enable
```

```
#configure terminal
```

```
MaxCore(config)#
```

```
MaxCore(config)#system 1
```

```
MaxCore(system-1)#?
```

The following table provides the list of System mode commands:

Table 5-4 Parameters of System mode commands

Argument	Description
eventFilterSeverity	Severity of the events to store. Event Severity is a 8 bit integer representing: 0 Disable (disable all logs), 1 Critical, 2 Major, 4 Minor, 8 Informational, 16 OK, 32 DEBUG, 255 All, It is possible to accumulate the values so that a combination of events can be filtered. Max allowed value is 255
eventFilterType	Type of the events to store. Event Type is a 16 bit integer representing: 0 Disable (disable all logs), 1 SSF_EVENT_TYPE_MASK_SENSOR, 2 SSF_EVENT_TYPE_MASK_SENSORENABLE, 4 SSF_EVENT_TYPE_MASK_WATCHDOG, 8 SSF_EVENT_TYPE_MASK_OEM, 16 SSF_EVENT_TYPE_MASK_SOFTWARE, 32 SSF_EVENT_TYPE_MASK_HOTSWAP, 64 SSF_EVENT_TYPE_MASK_RESOURCE, 128 SSF_EVENT_TYPE_MASK_DOMAIN, 256 SSF_EVENT_TYPE_MASK_USER, 512 SSF_EVENT_TYPE_MASK_REGISTRATION, It is possible to accumulate the values so that a combination of events can be filtered. Max allowed value is 1023
exit	Exit from system configuration mode
maxNoEvents	Maximum number events that can be stored in system
no	Negate a command or set its defaults
shelf	Configure shelf
show	Show running system information
softwareVersion	To display Management software information.
systemInfo	Describes the node
systemName	Name of the System
userConfig	User confirmation attribute for applying heterogeneous configurations. 0 - Yes, you can apply the configuration. 1 - No, do not apply the configuration

5.5 exit

The `exit` command is available at every mode of the system. This command allows you to exit from a particular mode.

Syntax

```
#exit
```

5.6 CLI Commands for Shelf Mode

All Shelf commands are available in shelf mode. To use the shelf commands, you need to enter into the shelf mode.

Syntax

```
>enable
```

```
#configure terminal
```

```
MaxCore(config)#
```

```
MaxCore(config)#system 1
```

```
MaxCore(system-1)# shelf 1
```

The following table provides the list of shelf mode commands.

Table 5-5 Parameters of Shelf mode commands

Argument	Description
BMCIPAddress	IP address of BMC. Set operation is not allowed here; Use Hardware Manager commands.
NoOfPCIEslots	Number of PCIe slots available on this shelf. PCIe slots value will be retrieved using BMC API such as "getSlotMap"
PCIEslot	Configure PCIeSlot
ShelfHostIPAddress	IP address of shelf host. Set operation is not allowed here; Use Hardware Manager commands.

Table 5-5 Parameters of Shelf mode commands (continued)

Argument	Description
shelfHostFailurePolicy	Describes the action configured upon the failure of shelf host; Set operation is not allowed here, please use Hardware Manager commands.
SATAConfiguration	SATA assignment - CPU address and the corresponding disk Ex: for slot 1 CPU 1 disk 1, the string is Slot 1,CPU 1 - Disk 1; Set operation is not allowed here, please use Hardware Manager commands.
USBConfiguration	USB assignment - CPU addresses and the corresponding USBs. Ex: for slot 1 CPU 1 USB 1, the string is Slot 1,CPU 1 - USB 1; Set operation is not allowed here, please use Hardware Manager commands.
alarm	Configure alarm.
bay	Configure alarm.
chassis	Configure chassis.
coolingPolicy	Contains the cooling policy for the fans in the chassis. Set operation is not allowed here; Use Hardware Manager commands.
inventoryInfo	Contains the shelf inventory information retrieved from the BMC Information will contain manufacturer information, part number, serial number and so on.
manufacturerId	Contains the manufacturer information of the shelf. This will be retrieved from shelf RU information using BMC. For example, Artesyn.
name	Represents the name of the shelf retrieved from shelf inventory information. For example, MaxCore.
NoOfPCIESlots	Number of PCIe slots available on this shelf. PCIe slots value will be retrieved using BMC API such as "getSlotMap".
partNumber	Contains the part number of the shelf. Value of this Attribute will be retrieved from BMC. For example, AB15467.
pexMode	PEX mode - BASE/FABRIC Set operation is not allowed here; Use Hardware Manager commands.
serialNumber	Contains the serial number of the shelf. Value of this Attribute will be retrieved from BMC. For example, 123N45.

Table 5-5 Parameters of Shelf mode commands (continued)

Argument	Description
shelfAddr	Contains the physical location of the shelf. The information can include building number, lab number, rack number and slot number. For example, 1.2.3.5 <building>.<lab>.<rack>.<slot in rack>
shelfHostAddress	Contains the shelf host address. Address format is as follows - {slot number <space> cpu number} For example, 1 1 Set operation is not allowed here; Use Hardware Manager commands.
shelfHostFailurePolicy	Describes the action configured upon the failure of shelf host. Set operation is not allowed here; Use Hardware Manager commands.
shelfPowerStatus	Contains the cold power status of the shelf. Value of this attribute will be retrieved using the BMC API (getFRUInstancePowerState)
switchPowerStatus	This method switch on shall move shelf from "shelf powered down" state to "shelf cold start" state and vice versa.
temperature	This attribute is to show the temperature of the shelf in degrees. For example, 40.
version	Contains the product version of the shelf. For example, MaxCore 1.0 and so on.

5.7 CLI Commands for PCIeSlot Mode

To use the PCIeSlot commands, you need to enter into the PCIeSlot mode. This section describes CLI navigation to enter into PCIeSlot mode.

Syntax

```
MaxCore (config) #
```

```
MaxCore (config) #
```

```
MaxCore (config) #system 1
```

```
MaxCore (system-1) #shelf 1
```

```
MaxCore (shelf-1-1) #PCIeSlot 1
```

The following table provides the list of PCIeSlot mode commands.

Table 5-6 Parameters of PCIeSlot mode commands

Argument	Description
PCIECard	Configure PCIECard
exit	Exit from PCIeSlot configuration mode.
IsPopulated	This attribute shows whether slot is populated or not (true/false).
name	Represents the name of the slot. For example, slot1.PCIE-7410.
no	Negate a command or set its defaults.
show	Show running system information.
slotMode	This will represent the configured mode (host or endpoint) of the slot. Value will be retrieved by the PEX configuration.
slotType	Represents the PCIe specification of the slot information such as version and lanes in conjunction. For example, PCIe3x1 PCIe3x2, PCIe3x4, PCIe3x8, PCIe3x16, PCIe3x32 and so on.

5.8 CLI Commands for PCIeCard Mode

To use the PCIeCard commands, you need to enter into the PCIeCard mode. This section describes CLI navigation to enter into PCIeCard mode.

Syntax

```
MaxCore(config)#system 1
```

```
MaxCore(system-1)#shelf 1
```

```
MaxCore(shelf-1-1)#PCIEslot 1
```

```
MaxCore(PCIEslot-1-1-1)#PCIECard 1
```

The following table provides the list of PCIeCard mode commands.

Table 5-7 Parameters of PCIeCard mode commands

Argument	Description
CPU	Configure CPU
CardConfiguration	Configure Card Configuration.
PCIeCardType	Represents the PCIe specification of the PCIe card information such as version and lanes in conjunction. For example, PCIe3x1 PCIe3x2, PCIe3x4, PCIe3x8, PCIe3x16, PCIe3x32 and so on.
PCIeVersion	Contains the version information of the PCIe card. Value of this attribute will be derived from the BMC API.
exit	Exit from PCIe Card configuration mode.
manufacturerId	Contains the manufacturer information of the PCIe card. This will be derived from the BMC API. For example, Artesyn, Intel and so on.
name	Contains the name of the PCIe Card. value of this attribute will be derived from the BMC API. For example, SharpServer, NIC-XL520, NIC-XL710 and so on.
no	Negate a command or set its defaults.
partNumber	Contains the part number of the PCIe card. Value of this Attribute will be retrieved from BMC API. For example, AB15467
productInformation	Contains the product information of the PCIe card. This will be derived from the BMC API. For example, XL520 (Niantic), XL710 (FortVille).
serialNumber	Contains the serial number of the PCIe card. Value of this attribute will be retrieved from the BMC API.
show	Show running system information.

5.9 CLI Commands for CPU Mode

To use the CPU commands, you need to enter into the CPU mode. This section describes CLI navigation to enter into CPU mode.

Syntax


```

MaxCore(config)#system 1
MaxCore(system-1)#shelf 1
MaxCore(shelf-1-1)#PCIEslot 1
MaxCore(PCIEslot-1-1-1)#PCIECard 1
MaxCore(PCIECard-1-1-1-1)#CPU 1
MaxCore(CPU-1-1-1-1-1)#?

```

The following table provides the list of CPU mode commands.

Table 5-8 Parameters of CPU mode commands

Argument	Description
BIOS	Configure BIOS.
CPUInformation	Contains the name of the CPU architecture family and also Operating frequency information. For example, BroadWell 2.10 GHz CPU.
CPUStatus	Represents the status of the CPU. For example, OK, Failed, HOT and so on.
endPoint_hdd_ND	Configure endPoint_hdd_ND.
endPoint_nic_ND	Configure endPoint_nic_ND.
exit	Exit from CPU configuration mode.
isMgmtCapable	Contains the details of the CPU is capable of management. This will be derived from the MCCS isShelfHost. If this CPU is chosen as shelf host by BMC, value will be set to true otherwise false.
manufacturerId	Contains the manufacturer details of the CPU. This will be derived from the MCCS.
name	Represents the name of the CPU. For example, CPU.1.
powerStatus	Power status of CPU - on/off
productId	Contains the product details of the CPU. This will be derived from the MCCS.
revision	Contains the product information of the CPU. This will be derived from the MCCS.

Table 5-8 Parameters of CPU mode commands (continued)

Argument	Description
show	Show running system information.
virExecEnv	Configure virExecEnv.
powerPolicy	Enable or disable power of CPU - On /Off.

5.10 CLI Commands for BIOS Configuration mode

This section describes CLI navigation to enter into BIOS Configuration mode.

```
#configure terminal
```

```
MaxCore(config)#
```

```
MaxCore(config)#system 1
```

```
MaxCore(system-1)#shelf 1
```

```
MaxCore(shelf-1-1)#PCIEslot 1
```

```
MaxCore(PCIEslot-1-1-1)#PCIECard 1
```

```
MaxCore(PCIECard-1-1-1-1)#CPU 1
```

```
MaxCore(CPU-1-1-1-1-1)#BIOS Configuration
```

```
MaxCore(BIOS-1-1-1-1-1-Configuration)#
```

The following table provides a brief description about the BIOS mode commands.

Table 5-9 Parameters of BIOS mode commands

Attribute	Description
bootOrder	Full name of a boot option, as it is shown by the BIOS. Set operation is not allowed here; Use Hardware Manager commands.
baudRate	IOS Setup > Advanced > Console Redirection > Baud Rate Set operation is not allowed here; Use Hardware Manager commands.

Table 5-9 Parameters of BIOS mode commands (continued)

Attribute	Description
skipShell	BIOS Setup > Advanced > Boot Configuration > Skip Internal EFI Shell Set operation is not allowed here; Use Hardware Manager commands.
autoReset	BIOS Setup > Advanced > Boot Configuration > Auto Reset. Set operation is not allowed here; Use Hardware Manager commands.
PCIeSRIOV	BIOS Setup > Advanced > Peripheral Configuration > PCIe SR-IOV Set operation is not allowed here; Use Hardware Manager commands.
PCIeARI	BIOS Setup > Advanced > Peripheral Configuration > PCIe ARI Set operation is not allowed here; Use Hardware Manager commands.
PCIe64bitDecode	BIOS Setup > Advanced > Peripheral Configuration > Pci 64-bit Decode Set operation is not allowed here; Use Hardware Manager commands.
spreadSpectrum	BIOS Setup > Advanced > Peripheral Configuration > Spread Spectrum Set operation is not allowed here; Use Hardware Manager commands.
VTD	BIOS Setup > Advanced > SIO Configuration > Intel VT for Directed I/O (VT-d) > Intel VT for Directed I/O (VT-d) Set operation is not allowed here; Use Hardware Manager commands.
interruptMapping	BIOS Setup > Advanced > SIO Configuration > Intel VT for Directed I/O (VT-d) > Interrupt Remapping Set operation is not allowed here; Use Hardware Manager commands.
SATAController	BIOS Setup > Advanced > PCH SATA Configuration > SATA Controller Set operation is not allowed here; Use Hardware Manager commands.

Table 5-9 Parameters of BIOS mode commands (continued)

Attribute	Description
SATAMode	BIOS Setup > Advanced > PCH SATA Configuration > HDC Configure As Set operation is not allowed here; Use Hardware Manager commands.
RAIDOROMDelay	BIOS Setup > Advanced > PCH SATA Configuration > SATA Mode options > RAID OROM prompt delay Set operation is not allowed here; Use Hardware Manager commands.
ALPMSupport	BIOS Setup > Advanced > PCH SATA Configuration > Aggressive LPM Support Set operation is not allowed here; Use Hardware Manager commands.
SATASpeedSupport	BIOS Setup > Advanced > PCH SATA Configuration > SATA Speed Support Set operation is not allowed here; Use Hardware Manager commands.
displayMode	BIOS Setup > Advanced > Video Configuration > Display Mode Set operation is not allowed here; Use Hardware Manager commands.
USBSupport	BIOS Setup > Advanced > USB Configuration > USB BIOS Support Set operation is not allowed here; Use Hardware Manager commands.
USBPort0	BIOS Setup > Advanced > USB Configuration > USB Port0 Set operation is not allowed here; Use Hardware Manager commands.
USBPort1	BIOS Setup > Advanced > USB Configuration > USB Port1 Set operation is not allowed here; Use Hardware Manager commands.
USBPort2	BIOS Setup > Advanced > USB Configuration > USB Port2 Set operation is not allowed here; Use Hardware Manager commands.
USBPort3	BIOS Setup > Advanced > USB Configuration > USB Port3 Set operation is not allowed here; Use Hardware Manager commands.

Table 5-9 Parameters of BIOS mode commands (continued)

Attribute	Description
USBPort4	BIOS Setup > Advanced > USB Configuration > USB Port4 Set operation is not allowed here; Use Hardware Manager commands.
USBPort5	BIOS Setup > Advanced > USB Configuration > USB Port5 Set operation is not allowed here; Use Hardware Manager commands.
USBPort6	BIOS Setup > Advanced > USB Configuration > USB Port6 Set operation is not allowed here; Use Hardware Manager commands.
USBPort7	BIOS Setup > Advanced > USB Configuration > USB Port7 Set operation is not allowed here; Use Hardware Manager commands.
hyperThreading	BIOS Setup > Advanced > Processor Configuration > Hyper-Threading [ALL] Set operation is not allowed here; Use Hardware Manager commands.
processorPerformance	BIOS Setup > Advanced > Processor Configuration > Performance/Watt Set operation is not allowed here; Use Hardware Manager commands.
executeDisableBit	Description - BIOS Setup > Advanced > Processor Configuration > Execute Disable Bit Set operation is not allowed here; Use Hardware Manager commands.
enableLTSX	BIOS Setup > Advanced > Processor Configuration > Enable LTSX Set operation is not allowed here; Use Hardware Manager commands.
VMX	BIOS Setup > Advanced > Processor Configuration > VMX Set operation is not allowed here; Use Hardware Manager commands.
hardwarePrefetcher	BIOS Setup > Advanced > Processor Configuration > Hardware Prefetcher Set operation is not allowed here; Use Hardware Manager commands.

Table 5-9 Parameters of BIOS mode commands (continued)

Attribute	Description
adjacentCachePrefetch	BIOS Setup > Advanced > Processor Configuration-> Adjacent Cache Prefetch Set operation is not allowed here; Use Hardware Manager commands.
directCacheAccess	BIOS Setup > Advanced > Processor Configuration > Direct Cache Access (DCA) Set operation is not allowed here; Use Hardware Manager commands.
X2APIC	BIOS Setup > Advanced > Processor Configuration > X2APIC Set operation is not allowed here; Use Hardware Manager commands.
EIST	BIOS Setup > Advanced > Advanced Power ManagementConfiguration > EIST (GV3) Set operation is not allowed here; Use Hardware Manager commands.
turboMode	BIOS Setup > Advanced > Advanced Power Management Configuration > CPU P State Control > Turbo Mode Set operation is not allowed here; Use Hardware Manager commands.
CPUCState	BIOS Setup > Advanced > Advanced Power Management Configuration > CPU C State Control > CPU C State Set operation is not allowed here; Use Hardware Manager commands.
CPUCStateLimit	BIOS Setup > Advanced > Advanced Power Management Configuration > CPU C State Control > Package C State limit Set operation is not allowed here; Use Hardware Manager commands.
CPUC3Report	BIOS Setup > Advanced > Advanced Power ManagementConfiguration > CPU C State Control > CPU C3 report Set operation is not allowed here; Use Hardware Manager commands.

Table 5-9 Parameters of BIOS mode commands (continued)

Attribute	Description
CPUC6Report	BIOS Setup > Advanced > Advanced Power Management Configuration > CPU C State Control > CPU C6 report Set operation is not allowed here; Use Hardware Manager commands.
enhancedHaltState	BIOS Setup > Advanced > Advanced Power Management Configuration > CPU C State Control > Enhanced Halt State (C1E) Set operation is not allowed here; Use Hardware Manager commands.
OSACPICx	BIOS Setup > Advanced > Advanced Power Management Configuration > CPU C State Control > OS ACPI Cx Set operation is not allowed here; Use Hardware Manager commands.
DTS	BIOS Setup > Advanced > Thermal Configuration > Cpu Thermal Configuration > DTS Set operation is not allowed here; Use Hardware Manager commands.
memoryFrequency	BIOS Setup > Advanced > Memory Configuration > Memory Frequency Set operation is not allowed here; Use Hardware Manager commands.
memoryHalt	BIOS Setup > Advanced > Memory Configuration > Halt on mem Training Error Set operation is not allowed here; Use Hardware Manager commands.
numa	BIOS Setup > Advanced > Common RefCode Configuration > Numa Set operation is not allowed here; Use Hardware Manager commands.
bootType	Boot > Boot Type Set operation is not allowed here; Use Hardware Manager commands.
PXEBoot	Boot > NetworkStack Set operation is not allowed here; Use Hardware Manager commands.

Table 5-9 Parameters of BIOS mode commands (continued)

Attribute	Description
PXEBootCapability	Boot > PXE Boot capability Set operation is not allowed here; Use Hardware Manager commands.
USBBoot	Boot > USB Boot Set operation is not allowed here; Use Hardware Manager commands.

5.11 CLI Commands for VEE mode

This section describes CLI navigation to enter into Virtual Execution Environment (VEE) mode.

```
#configure terminal
MaxCore(config)#
MaxCore(config)#system 1
MaxCore(system-1)#shelf 1
MaxCore(shelf-1-1)#PCIEslot 1
MaxCore(PCIEslot-1-1-1)#PCIECard 1
MaxCore(PCIECard-1-1-1-1)#CPU 1
MaxCore(CPU-1-1-1-1-1)#virExecEnv 0
MaxCore(virExecEnv-1-1-1-1-1-0)#
```

The following table provides a brief description about the VEE commands.

Table 5-10 Parameters of VEE mode commands

Attribute	Description
collectLog	Collects the system log files.
diagnostic	Configure diagnostic.
endPoint_HDD	Configure endPoint_HDD.

Table 5-10 Parameters of VEE mode commands (continued)

Attribute	Description
endPoint_NIC	Configure endPoint_NIC.
exit	Exit from virExecEnv configuration mode.
firmWareVersion	Firmware version returns the firmware version of the PCIe blade and the application version also value will be retrieved using BBS tool.
firmwareUpgrade	Upgrades the Firmware. Parameter will change as per the upgrade procedure provided.
getHistoricalSensorData	This functions gets the historical sensor data of the site such as time interval, threshold min, threshold max, current value.
getSensorData	This functions gets the sensor data of the site such as time interval, threshold min, threshold max, current value. Sensor data is retrieved using BBS tools.
interface	Configure interface.
linuxApplication	Configure linuxApplication.
listDevices	Lists available devices for firmware upgrade in the blade This will be retrieved using BBS tool.
listDisks	Provides a list of disks discovered by the OS along with type, vendor, capacity and usage.
listPciEndPoints	This method lists the PCIe end points attached to this VM instance PEX config API will be used for this operation.
listSensors	This function returns the list of sensors on PCIe card such as temperature, voltage, power and so on. This list of sensors is retrieved using BBS tools.
maxCoreFirmwareUpgrade	Firmware upgrade method upgrades the firmware on boards at each level in the MaxCore hierarchy.
maxCoreSystemUpdate	This method accepts the complete update package, unpacks it and performs the updates on a card in sequence.
name	This attribute represents the OS as host OS or vm1, vm2 and so on.
no	Negate a command or set its defaults.

Table 5-10 Parameters of VEE mode commands (continued)

Attribute	Description
osVersion	OS Version information of VM running. This will be returned using the Linux command.
reboot	To reboot the VEE. This will reboot the VM which results in SSF components restart also.
scp	Copies the files from current VM to remote location using Linux scp.
show	Show running system information.
shutdown	To bring down the current VM.
switch	Configure switch
sysInfo	Shows the System Information of the VM such as uptime, date, meminfo and so on.
tcpdump	Dump traffic on a network. This method makes use of the linux tcpdump command.
updateSensorThresholds	This functions updates the sensor limits of site such as threshold min, threshold max updateSensor threshold values will be done using BBS tool.

5.12 CLI Commands for Linux Application mode

This section describes CLI navigation to enter into Linux Application mode.

```
#configure terminal
```

```
MaxCore(config)#
```

```
MaxCore(config)#system 1
```

```
MaxCore(system-1)#shelf 1
```

```
MaxCore(shelf-1-1)#PCIEslot 1
```

```
MaxCore(PCIEslot-1-1-1)#PCIECard 1
```

```
MaxCore(PCIECard-1-1-1-1)#CPU 1
```

```
MaxCore(CPU-1-1-1-1-1)#virExecEnv 0
```

```
MaxCore(virExecEnv-1-1-1-1-1-0)#linuxApplication syslcu
```

```
MaxCore(linuxApplication-1-1-1-1-1-0-syslcu)#?
```

The following table provides a brief description about the Linux Application commands.

Table 5-11 Parameters of Linux Application mode commands

Attribute	Description
commit-config	Commit the configuration for a Linux application to consume. This method also restarts the service with the latest configuration.
description	General description about the Linux service describing the functionality of the application.
edit-config	Edit the configuration file of a Linux application.
exit	Exit from LinuxApplication configuration mode.
listConfigFiles	This method returns the list of config files for the Linux application.
name	Represents the name of the application. For example, syslog-ng.
reload	This method reloads a new configuration of the Linux application without restarting it.
restart	This method restarts the Linux application.
show	Show running system information.
start	This method starts a Linux application.
status	Operational Status of the Linux application values are: 0 - STOPPED 1 - RUNNING.
stop	This method stops the running Linux application.
upload-config	Upload a configuration file to the Core. This is method will not be exposed to user. This will be used for internal development purpose.

System Log Collection Commands

System Log Collection commands are used to collect system logs from different cards to SSF core and then to download those from SSF core to the user specified locations.

When user triggers `collectlog` command, SSF core will start collecting the logs at the specified location and then it will put the collected log files in `tar.gz` format in SSF core predefined location `"/var/log/ssf/system_logs"`.

These commands can be executed at any level through out the system hierarchy.

6.1 collectlog

The `collectlog` command collects the required system log files at the specified MOID level and keep the files in tar format at the predefined directory in the SSF core. The predefined directory is `"/var/log/ssf/system_logs"`. The following are the input arguments required for this command.

Syntax

```
#collectlog filename <filename> size <size>
```

Argument	Description
filename	The file name with which log tar ball should be created in SSF core location
size	The maximum file size to be used for storing the data and it should not exceed the available size in that partition. The available size can be get from 'ssflogsize' command

6.2 listlog

The `listlog` command lists all the collected log file names with comma (",") separator between each file. It doesn't require any input arguments.

Syntax

```
#listlog
```

6.3 deletelog

The `deletelog` command deletes all the collected log files from the SSF Core. It does not require any input arguments.

Syntax

```
#deletelog
```

6.4 ssflogsize

The `ssflogsize` command provides the free space available in the system partition, where all SSF core collected log files will be placed. The output will be free memory size in MBs. It does not require any input arguments.

Syntax

```
#ssflogsize
```

6.5 downloadlog

The `downloadlog` command downloads the user's selected log file to the specified location using FTP protocol. User has to make sure that the provided remote path should have read-write permissions to copy files to their FTP server location.

Syntax

```
#downloadlog serverip <serverip> username<username> password  
<password> remotepath <path> filename <filename>
```

Argument	Description
<code>serverip</code>	User server IP address.
<code>username</code>	User name for login to the user server.
<code>password</code>	Password for the specified user name to login to the user server.
<code>path</code>	Location on the user server where the downloaded logs are to be kept.
<code>filename</code>	Name of the Log file, which user wants to download from SSF core to user's specified location in path argument.

Related Documentation

A.1 Artesyn Embedded Technologies - Embedded Computing Documentation

The publications listed below are referenced in this manual. You can obtain electronic copies of Artesyn Embedded Technologies - Embedded Computing publications by contacting your local Artesyn sales office. For released products, you can also visit our Web site for the latest copies of our product documentation.

1. Go to www.artesyn.com/computing/support/product/technical-documentation.php.
2. Under FILTER OPTIONS, click the Document types drop-down list box to select the type of document you are looking for.
3. In the **Search** text box, type the product or manual name and click Filter.

Table A-1 Artesyn Embedded Technologies - Embedded Computing Publications

Document Title	Publication Number
SSF for MaxCore™ MC3000 Platform XML Interface Guide	6806800T71
MaxCore™ MC3000 Platform Installation and Use	6806800T88
MaxCore™ MC3000 Platform Quick Start Guide	6806800T89
MaxCore™ MC3000 Platform Safety Notes Summary	6806800T90
Getting Started with MaxCore™ MC3000 Application Note	6806800T98
MaxCore™ MC3000 Platform Software Installation and Use	6806800U97



Artesyn Embedded Technologies, Artesyn and the Artesyn Embedded Technologies logo are trademarks and service marks of Artesyn Embedded Technologies, Inc. All other product or service names are the property of their respective owners.

© 2017-2018 Artesyn Embedded Technologies, Inc.